

CABIN AIR SPRINGS (Without Shock Absorber)



1

2

3

4

5

6

7

8

9

10

C 321 101

C 321 201

C 321 202

C 321 051

C 321 053

C 321 054

C 210 05

C 210 06

C 210 07

CONNECT CODE	AIRKRAFT REF.	BLACKTECH REF.	TYPE	VEHICLE	Part No.
C 321101	121101	110 01 C	SACHS - Without Shock Absorber	SCANIA 93 - 113 - 143 (Front - Rear)	OEM 1348121 - 1314278 / SACHS 481002 / SABO 895222 / MONROE CB0066
C 321201	121201	110 08 C	SACHS - Without Shock Absorber	SCANIA 94 - 114 - 144 (Front - Rear)	OEM 1349840 / SACHS 557001 / SABO 895220 / MONROE CB0077
C 321202	121202	110 02 C	MONROE - Without Shock Absorber	SCANIA 94 - 114 - 144 (Front - Rear)	OEM 1476415 - 1381919 / MONROE 717262725 - CB0030
C 321051	121051	210 01 C	Without Shock Absorber	RENAULT V.I. PREMIUM (Front)	OEM 5010 130 797 G / CONTI SZ 50 9 / SABO 895266
C 321053	121053	210 02 C	Without Shock Absorber	RENAULT V.I. G 340 Ti (Front - Rear)	OEM 5010 092 916 E / CONTI SZ 50-8
C 321054	121054	210 04 C	Without Shock Absorber	RENAULT G 340 Ti (Front - Rear)	OEM 5010 266 845 A / CONTI SZ50-10
C 21005		210 05 C	Without Shock Absorber	RENAULT GAMME G	CONTI SZ 50-6
C 21006	-	210 06 C	Without Shock Absorber	-	CONTI SZ 51-5
C 21007	-	210 07 C	Without Shock Absorber	-	CONTI SZ 51-10
C 410 01	125101	410 01 C	Seat Air Spring	PILOT Seat	CONTI SZ 51-7